

AMD Direct

HEAT-DISPLAY-HARDWARE

CAUTION: For safety, it is recommended for at least two people to install this unit. Please install heaters after mounting the HEAT-DISPLAY-BKT to heater stand.

Step 1: Open the packaging of the heater you intend to display, locate mounting bracket(s), installation guide, and hardware. Set heater hardware aside.

Step 2: Use AMD provided 10-24 screws, locking washers, and nuts to attach the respective heater bracket from Step 1 to the HEAT-DISPLAY-BKT by inserting the screw in from the heater stand side towards the mounted heater. Place locking washer then nut. Tighten nut. See CIRCLES on Figs 1 & 2.



Fig 1




Fig 2

Step 3: Use mounting hardware from heater to mount heater onto heater bracket. See ARROWS on Figs 1 & 2.